

Walker Bag

Use Heavier woven fabrics (cotton twill, poly/cotton blends and Upholstery fabrics)
You may use fusible interfacing for additional support on lighter weight fabrics.

Cut 1 18 x 27 inches for front and back. (or cut 2 18 x 14 inches and seam with a ½" seam.)

Cut 18 x 9 inches for pocket.

Cut 2 rectangles 12 x 6 inches for the tabs.

Cut 2 pieces of ¾" or 1 inch wide Velcro 2 ¼"

Finishing off the top edge of the front, back & pocket

Serge the edges trimming off ½" as you serge ...Fold down 1 ½". Press, Sew down with a straight stitch on top of the serged stitching. If you do not have a serger, fold down ½". Press, Fold down 1 ½". Press, sew along the edge of the fold with a straight stitch.

Divide the pocket into two sections and mark. Mark pocket placement 1 inch from the bottom. Sew across bag & pocket with a ½" seam. Hold pocket towards the top and top-stitch across pocket. On the dividing line sew up and back down with a ¼" space between stitched lines.

Sew side seams with a ½" seam and either serge or zig-zag the seam allowance.

For the handles, fold the 12 x 6 rectangles in half with right sides together. Sew along the long side and across one end. Turn & press. On the unfinished end, fold in half and sew across, forming a pointed end. Place the finished end 2" in from the side and 1" down from the top edge of the back. Sew with a rectangle and X. On the front Attach Velcro 2" from the side on the front. Sew the matching Velcro to the pointed end of the handle leaving the point free.

Note: BE SURE THE HANDLES ARE EVEN OR THE BAG WILL NOT HANG PROPERLY ON THE WALKER